




Autohelm[®]

**ST 50
PLUS**

DEPTH

Operation and
Installation




Package Contents

The following items are included in the ST50 Plus Depth package:

1. ST50 Plus Depth control head
2. Fixing studs (2 off)
3. Thumb nuts (2 off)
4. Fitting template
5. Power cable
6. Depth transducer (through hull) with 14m (45ft) of cable
7. Control head cover
8. Operation and Installation handbook
9. Worldwide Service Centre handbook
10. Warranty document
11. Security code sticker

ST50 Plus Depth Operation and Installation Handbook



Contents

Introduction	1
Chapter 1: Control Head Installation	3
1.1 Siting	3
1.2 Mounting Procedure	4
1.3 Power Supply (stand-alone operation)	6
1.4 Power Supply (SeaTalk operation)	6
1.5 Connection of Separated Instruments	7
1.6 Ring Connection	8
1.7 Connection to SeaTalk Compatible Autopilots	8
Chapter 2: Transducer Installation	9
2.1 Connection to the Control Head	9
2.2 Transducer Selection	9
2.3 Transducer Installation	9
Chapter 3: Fault Finding and Maintenance	13
3.1 Fault Finding	13
3.2 Maintenance	14
Chapter 4: Operation	15
4.1 Depth Key	16
4.2 Alarm Key	18
4.3 Offset Key	20
4.4 Reset Key	21
4.5 Display Contrast	22
Chapter 5: CODE Lock Security	23
Chapter 6: Calibration	27

Introduction


The ST50 Plus Depth is a SeaTalk compatible, multi-function instrument that employs a powerful echo sounder to give excellent performance over a wide range of sea conditions.

Deep, shallow, anchor watch alarms can be set to provide visual and audible warnings when the water depth reaches selected thresholds.


The ST50 Plus Depth can be configured to operate as a master unit or a dedicated repeater. All settings are stored in permanent memory and retained even when the power source is disconnected.

The ST50 Plus Depth also incorporates a security feature to protect instruments mounted in vulnerable areas such as the cockpit, helm or mast.

Thank you for purchasing an Autohelm product. May we take this opportunity to wish you years of trouble free operation.



Chapter 1: Control Head Installation




1.1 Siting

The ST50 Plus Depth is designed for above or below deck installation where it is:

- Easily readable by the helmsman
- Protected against physical damage
- At least 230mm (9in) from a compass
- At least 500mm (20in) from radio receiving equipment
- Accessible from behind for ease of installation and cable running

Caution:

To prevent moisture forming on the display window, the ST50 Plus Depth 'breathes' through a small vent in the cable boss. Therefore, the control head must be sited where the rear case is protected from contact with water.



1 Cable boss 2 Fixing studs 3 Thumb nuts 4 Gasket

1.2 Mounting Procedure

1. Make sure that the selected location is clean, smooth and flat.
2. Apply the self-adhesive template (supplied) to the selected location and mark the centres for the fixing studs (2) and the cable boss (1).
3. Drill two 4mm (5/32in) clearance holes for the fixing studs (2) through the bulkhead. Remove the template.
4. Cut the clearance hole for the cable boss (1) using a 50mm (2in) diameter cutter.
5. Screw the two fixing studs (2) into the control head.
6. Pass the SeaTalk cable and transducer tails through the cable-boss (1) clearance hole.
7. Assemble the control head to the bulkhead and secure from behind using the thumb nuts (3).

Note:


Bracket Mounting

The ST50 Plus Depth can, as an alternative, be bracket mounted using the Autohelm Mounting Kit.




Flush Mounting

A flush mounting kit is available for installations where a flush mount is required or more desirable. Full installation instructions are provided with the kit.



1.3 Power Supply (stand-alone operation)



1. Connect the 2m (6ft.) power supply cable directly to the distribution panel.
2. Cut the cable to length and connect the red wire to the +12V terminal and screen to the 0V terminal.
3. Cut back and insulate the yellow wire.
4. Protect the circuit with a 5A circuit breaker.

Longer runs to the power supply can be made using the 9m (30ft) SeaTalk Extension Cable (D131).

1.4 Power Supply (SeaTalk operation)

All instruments in a SeaTalk system receive power and information from the SeaTalk bus. Each instrument has two SeaTalk connectors (3 pin) on 150mm (6in) tails. To supply power and information to the instrument simply plug adjacent tails into the ST50 Plus Depth tails.




1.5 Connection of Separated Instruments

Separated instruments can be connected using one of the range of SeaTalk Extension Cables. These cables are supplied with a SeaTalk connector fitted to each end. A junction box can be used to join the cable if it is cut for easier routing or shortening.

If preferred, any 2 core, screened cable conforming the following specification may be used instead of the SeaTalk cable.

- 22 AWG, 2 core screened cable with a minimum copper area of 0.5mm².



1.6 Ring Connection

Installations with large numbers of instruments on a SeaTalk bus may require a second ring-main connection to the power supply breaker to prevent excessive voltage drops. Refer to the following list to determine whether a second ring main is necessary.

Cable run upto 10m (33ft)

Single connection: 13 instruments maximum

Second connection: 26 instruments maximum

Cable run upto 20m (66ft)


Single connection: 7 instruments maximum

Second connection: 13 instruments maximum

The second ring-main should be connected to the spare lead on the last instrument in the chain and directed back to the circuit breaker.

1.7 Connection to SeaTalk Compatible Autopilots


If the installation includes a SeaTalk compatible Autopilot the ST50 instruments may be connected to the SeaTalk bus at any point. No independent connection to the 12V power supply is necessary as the instruments receive power from the Autopilot course computer.



Chapter 2: Transducer Installation

2.1 Connection to the Control Head

The depth transducer is supplied, as standard, with a through hull fitting and 14m (45ft) of cable. The cable is equipped with a SeaTalk connector that plugs into a control head connector.




2.2 Transducer Selection

The type of depth transducer used is governed by the hull material. The following list shows the appropriate transducer for hull type.

Transducer Type	Hull Material
Z091 Through Hull Plastic:	GRP (Glass Reinforced Plastic), Steel and Aluminium
Z118 Through Hull Bronze:	Wood
Z120 Retractable through-hull:	GRP (Glass Reinforced Plastic), Steel and Aluminium

Siting


For accurate depth readings the transducer should be sited within the shaded clear flow areas.



1 Sail 2 Planning power 3 Displacement power

The transducer should also:

- be ahead of the propellers (10% W.L. length minimum)
- be at least 150mm (6in) away from the keel (ideally ahead of the keel if a sailing yacht)
- be as near as possible the centreline of the vessel
- be clear of other through-hull fittings or projections
- have sufficient clearance inside the hull to fit the nut
- have 100mm (4in) of headroom to allow for withdrawal



Cabling

1. Run the cable back to the control head.

Note:

Avoid fluorescent lights, engines, radio transmitting equipment etc. as these may cause interference. Also, keep the transducer cable clear of the bilge and secure at regular intervals.

2. Fit the transducer and instrument cable connectors together. To lock the connectors, push and rotate the ring on the transducer cable connector towards the control head connector.

Chapter 3: Fault Finding and Maintenance

3.1 Fault Finding

All Autohelm products are, prior to packing and shipping, subjected to comprehensive test and quality assurance programmes. However, if a fault arises with the ST50 Plus Depth, the following table will help to identify the probable cause and provide the most likely cure.

Fault	Cause	Action
Instrument display blank.	No supply.	Check supply. Check cabling and security of SeaTalk connectors. Check fuse/breaker. Return unit for repair.
Instrument displays 'CODELOCK set', ENTER CODE.	The 'CODE Lock' feature has been set.	Enter correct code number.
No exchange of information between SeaTalk instruments (ie, illumination levels).	SeaTalk cabling problem.	Check security of SeaTalk connectors. Remove instruments one by one to isolate faulty unit.
Failure of a group of instruments in SeaTalk chain.	SeaTalk cabling/connector problem.	Check security of SeaTalk connectors between functioning and non-functioning instruments.
Depth reading continuously flashes (Depth greater than 3 feet).	Transducer cable/connector problem.	Check cabling and security of transducer connector.
Depth reading flashes while underway.	Aerated water, boat wakes, propellor wash etc.	Normal reading will return when clear of disturbed water.

3.2 Maintenance

Instrument

Certain atmospheric conditions may cause condensation to form on the control head window. This will not harm the unit and can be cleared by increasing the illumination setting to Level 3.

Chemical and abrasive materials must not be used to clean the control head; if it is dirty, clean with a soft, damp cloth.

Transducer

Refer to the Installation and Maintenance instructions supplied with the transducer.

Cabling

Examine all cables for chafing or damage to the outer shield and, where necessary, replace and resecure.

Advice

For advice, or further information regarding the installation of this product, please contact the Autohelm product Support Department or your own National Distributor.

Chapter 4: Operation

As it leaves the factory the ST50 Plus Depth is set with:

- depth units in feet
- transducer offset set to 0 feet
- shallow alarm set to 10 feet
- deep alarm set to 100 feet
- low anchor alarm set to 50 feet
- high anchor alarm set to 50 feet


These settings can be changed in calibration, Chapter 6.

When the unit is powered-up for the first time water depth will be displayed.

Note:

If during a 10 second period no valid echoes are received, the deep legend will flash (if the depth is greater than 100ft) after a 10 second delay to indicate that the display is not being updated and that the currently displayed value was the last valid echo.

4.1 Depth Key



Depth Key Notes

Minimum Depth

Minimum depth can be reset by pressing **RESET**.

Minimum depth returns to current depth after 8 seconds.


Display Contrast

The display contrast is automatically adjusted when the lights are turned on.

Fathoms

When the units of measure are set to feet, fathoms will be displayed before minimum depth.

4.2 Alarm Key



Alarm Notes

Shallow Alarm

The shallow alarm has priority over all alarms.

The shallow alarm will sound until it is silenced, however, the shallow alarm legend continues to flash until the depth rises above the set threshold.

Deep Alarm

The deep alarm is triggered when crossing the set threshold going from shallow to deep and deep to shallow waters.

Unless it is silenced, the deep alarm sounds for 30 seconds.

Anchor Alarms

The anchor alarms provide visual and audible warnings when the water reaches critical low or high levels when the vessel is anchored.

These alarms can be silenced, however, the visual alarm will continue to flash until a safe water depth has been reached.


Silencing Audible Alarms

Audible alarms can be silenced by pressing any key.

Enabling and Disabling Alarms

All alarms can be disabled. For further details, please refer to the calibration section.

4.3 Offset Key




Offset Key Notes

The offset value can be positive or negative: depth measured from the keel is negative and depth to the waterline positive.

The offset display will return to water depth 8 seconds after the last key press

4.4 Reset Key




Reset Key Notes

This feature allows the depth units to be switched between feet and metres. However, the units can only be toggled when the current water depth is displayed.

4.5 Display Contrast

The contrast can be adjusted to achieve optimum legibility at any angle.



1. Momentarily press **DEPTH** and **ALARM** together.
2. Press **OFFSET** or **RESET** to increase or decrease the contrast setting (the range being between 1 and 15).

Note:

A high setting will suit installations where the control head will be viewed from above.

3. Press **DEPTH** and **ALARM** together momentarily to store the contrast setting.

Chapter 5: CODE Lock Security

The ST50 Plus range incorporates an anti-theft feature called 'CODE Lock'. Designed to protect individual instruments or complete systems in vulnerable areas, 'CODE Lock' is a four digit number that you programme into the permanent memory of a selected 'master' instrument.

Note:

A 'master' instrument is a digital unit on which the code number can be entered, and then, if part of an integrated system, transmitted to other ST50 Plus instruments.

This facility means that, should a CODE Locked instrument be removed from a vessel without the owners permission, it cannot be operated without the four digit security number.


'CODE Lock' can be used in one of three modes:

Mode 1: Off

As it leaves the factory 'CODE Lock' is set to off. In this mode the instrument will operate normally when it is switched on, however, the unit will not be protected by the anti-theft feature.

Mode 2: CODE Lock Once-Only Entry (page 25)


This mode is designed for systems with a digital ST50 Plus instrument in a safe, below-decks location. This instrument can then be used as a 'master' to enter the four digit code number, and automatically transmit the code to all the instruments in the system when the power is switched on. The advantage of this mode is that, with the master safely below deck, code entry via the keypad is a once-only operation on installation.



Mode 3: CODE Lock input at Power-On (page 26)

In the 'Power-On mode', the ST50 Plus is configured so that you have to enter the four digit number on the master instrument every time the system is switched on. **Until this number is entered the instrument(s) will not operate.**

This mode is particularly useful when you are unable to position a 'master' instrument below decks and, therefore, all the vessels valuable instrumentation is left in a vulnerable area.



Should a CODE Locked instrument be removed from the system, it will not operate until the correct four digit security number is entered or received.

If your selected master instrument fails for any reason, the security code number can be entered via another ST50 Plus instrument in the system. However, until another instrument is set as a master or the existing master is replaced, the security code will have to be entered every time the system is switched on.


Note:

A warning sticker is provided with each instrument. If you have set 'Code Lock', position this warning sticker in a prominent location to deter potential thieves.

Mode 3: CODE Lock input at Power-On (page 26)

In the 'Power-On mode', the ST50 Plus is configured so that you have to enter the four digit number on the master instrument every time the system is switched on. **Until this number is entered the instrument(s) will not operate.**

This mode is particularly useful when you are unable to position a 'master' instrument below decks and, therefore, all the vessels valuable instrumentation is left in a vulnerable area.



Should a CODE Locked instrument be removed from the system, it will not operate until the correct four digit security number is entered or received.

If your selected master instrument fails for any reason, the security code number can be entered via another ST50 Plus instrument in the system. However, until another instrument is set as a master or the existing master is replaced, the security code will have to be entered every time the system is switched on.

Note:

A warning sticker is provided with each instrument. If you have set 'Code Lock', position this warning sticker in a prominent location to deter potential thieves.

Once Only Entry

Action	Display Shows
1 Press and DEPTH and ALARM together for 4 seconds	CAL after 2 seconds and VER X.X after 4 seconds
2 Press DEPTH twice	CODELOCK Cal. Off
3 4 seconds after CODELOCK Cal. Off	ENTER CODE
4 Press ALARM	' _ _ _ _
5 Press OFFSET or RESET to select first number	1 _ _ _
6 Press ALARM to accept number	1' _ _ _
7 Press OFFSET or RESET to select second number	1 2 _ _
8 Press ALARM to accept number	1 2' _ _
9 Press OFFSET or RESET to select third number	1 2 3 _
10 Press ALARM to accept third number	1 2 3' _
11 Press OFFSET or RESET to select fourth number	1 2 3 4
12 Press ALARM to accept code	'1 2 3 4'
13 Press ALARM	PWR ON?
14 Leave PWR ON? flashing for 10 seconds	CODELOCK Cal. set
15 To save code, press DEPTH and ALARM together for 2 seconds	Normal operation, eg. depth display

T1101

If you do not exit 'CODELOCK Cal. set' within 10 seconds, the display will change to CANCEL CODE. You now have the option of cancelling the code, by pressing **ALARM** to return to the _ _ _ _ display, or exit as described in action 15 above.

Your Code Number

For future reference, enter your chosen code number in the following box.

On Power-Up

	Action	Display Shows
1	Press and DEPTH and ALARM together for 4 seconds	CAL after 2 seconds and VER X.X after 4 seconds
2	Press DEPTH twice	CODELOCK Cal. Off
3	4 seconds after CODELOCK Cal. Off	ENTER CODE
4	Press ALARM	' _ _ _ _
5	Press OFFSET or RESET to select first number	1 _ _ _
6	Press ALARM to accept number	1 ' _ _ _
7	Press OFFSET or RESET to select second number	1 2 _ _
8	Press ALARM to accept number	1 2 ' _ _
9	Press OFFSET or RESET to select third number	1 2 3 _
10	Press ALARM to accept third number	1 2 3 ' _
11	Press OFFSET or RESET to select fourth number	1 2 3 4
12	Press ALARM to accept code	'1 2 3 4'
13	Press ALARM	PWR ON?
14	Press ALARM within 10 seconds	CODELOCK Cal. set
15	To save code, press DEPTH and ALARM together for 2 seconds	Normal operation, eg. depth display

T1121

If you do not exit 'CODELOCK Cal. set' within 10 seconds, the display will change to CANCEL CODE. You now have the option of cancelling the code, by pressing **ALARM** to return to the _ _ _ _ display, or exit as described in action 15 above.

Your Code Number


For future reference, enter your chosen code number in the following box.

--	--	--	--

Chapter 6: Calibration

As it leaves the factory the ST50 Plus Depth is set to display depth units in feet. These settings, together and other navigational features, can be changed (e.g., Feet to Metres) as described in this section.

6.1 Initial Calibration



Initial Calibration Notes

Alarms

The shallow, deep, low anchor, high anchor and offset displays can be adjusted using the **OFFSET** and **RESET** keys.

The **ALARM** key is used to enable/disable the alarms.


Units

Alternating between feet and metres is achieved by pressing **RESET**.

Exit Initial Calibration

To exit initial calibration and store the new settings, press **DEPTH** and **ALARM** together for 2 seconds.

6.2 Intermediate Calibration



Intermediate Calibration Notes

Repeater Mode

Repeater mode allows the ST50 Plus Depth to repeat speed related data already on the SeaTalk bus. There are two settings:

0=disabled and 1=enabled.


Note:

Initial calibration cannot be accessed when the unit is configured as a repeater.

Exit Intermediate Calibration

To exit intermediate calibration and store the new settings, press **DEPTH** and **ALARM** for 2 seconds.

6.3 Extended Calibration



Extended Calibration Notes

All of the extended calibration screens are adjusted using the **OFFSET** and/or **RESET** keys.

Calibration

Calibration allows you to protect your selected settings. When calibration is enabled the initial and intermediate calibration settings cannot be modified.

CAL 0 = Calibration locked, i.e. no access

CAL 1 = Calibration unlocked, i.e. normal access

Once locked, calibration can be unlocked by entering extended calibration and selecting 1, calibration unlocked.

Depth Damping

Depth damping adjusts the rate at which the display is updated. The default setting is 4 seconds, however, the selectable range is 1 to 15.

Boat Show

The 'Boat Show' mode is a dealer demonstration program only. Under no circumstances must this program be engaged when this unit is installed onboard your vessel.

Exit Extended Calibration

To store the extended calibration settings, press **DEPTH** and **ALARM** for 2 seconds.

Chapter 7: General Specification

Dimensions:	110 x 110mm (4.33 x 4.33in)
Power supply:	10 to 16V
Power consumption:	50ma (normal) 100ma (illumination on)
Temperature range:	0 to 70 deg.C
Depth:	0 to 600 feet (0 to 180 metres)
Shallow alarm:	3 to 33 feet (1 to 10 metres)
Deep alarm:	10 to 400 feet (3 to 120 metres)
Offset:	-9.9 to 9.9 feet (-4 to 4 metres)
Anchor alarm:	0 to 600 feet (0 to 180 metres)
Minimum depth function:	Reset on power-up
Units:	Software programmable feet/fathoms or metres
Damping:	1 to 15 seconds
Repeater capability:	Software programmable
Illumination:	3 levels plus off